

## TEST PROCEDURE How to perform the test





2. Add 3 drops of Conjugate to both lower ports. Incubate for 2 minutes at 22-25 C.



Add 3 drops of Wash Buffer to both upper ports. Allow Wash Buffer to absorb.



 Add 2 drops of Substrate to both upper ports. Incubate for 5 minutes at 22-25 C. Interpret visually.

## **INTERPRETATION OF RESULTS**







## READ ONLY UPPER REACTION PORTS TO INTERPRET RESULTS

This illustration is representative of the current Package Insert at the time of publication. Please refer to the most current version of the package insert for complete instructions.

USA/Corporate Office 3471 River Hills Drive Cincinnati, Ohio 45244 Telephone: 513.271.3700 www.meridianbioscience.com Orders / Customer Service: 1.800.543.1980 Technical Support: 1.800.343.3858 Information Fax: 513.272.5432 Ordering Fax: 513.271.0124



© 2009 SN11232, REV. 01/10