


monospot[®]


Latex

TEST PROCEDURE


How to perform the test




1. Apply 1 drop of Positive Control and 1 drop of Negative Control onto appropriately marked circles.




2. Using the provided Pipetstir, apply 1 drop of specimen onto the marked circle.



3. Add 1 drop of the Latex Reagent to each of the control circles and the specimen circle.



4. Mix thoroughly.



5. Rotate the slide for 3 minutes at 80 - 100rpm.



6. Examine circles for visible agglutination.



This illustration is representative of the current Package Insert at the time of publication. Please refer to the most current version of the Package Insert for complete instructions.

USA/CORPORATE OFFICE

3471 River Hills Drive
Cincinnati, Ohio 45244 USA
Telephone: 513-271-3700

MERIDIAN BIOSCIENCE EUROPE

Belgium/Luxembourg Tel: +32 (0)6789 5959
France Tel: +33 (0)1 4256 0440
Germany Tel: +49 (0)3371 60 222 31
Italy Tel: +39 0331 43 3636
Netherlands Tel: +31 (0)411 62 11 66
United Kingdom Tel: +44 (0)20 8453 7970

©2019 SN5926 REV. 03/19

Orders/Customer Service: 1-800-543-1980
Technical Support: 1-800-343-3858
Information Fax: 513-272-5432
Ordering Fax: 513-271-0124
meridianbioscience.com

meridian BIOSCIENCE™